Used for breaking a section of aspirating smoke detection pipe network for maintenance purposes. This device is designed for aspirating fire detection only.

Installation Instructions:

SOCKET UNION

(ABS003 - 27mm)

Use the correct solvent Plusbond 3019. Do not paint. Keep pipe clean and free from dust. Do not install in direct sunlight. Only install with approved pipe. Do not use solvents to clean, only soapy water. Do not over tighten. Keep O'Ring in place. Ensure that the socket union locks into position when tightening.



