## **BLOW THROUGH VALVE**

(R-PVCBOV - 25mm)



A blow off valve is positioned towards the end of a pipe run, it allows dust to be blown out of the system, by attaching a compressed air line and opening the valve.

## **Installation Instructions:**

Use the correct solvent Plusbond 3019. Do not paint. Keep pipe clean and free from dust. Only install with approved pipe. Do not use solvents to clean, only soapy water.

PART NO.:

Red

R-PVCBOV - 25mm

FITTINGS COLOUR:

**PIPE COLOUR:** Red

DIAMETER TOLERANCE:

+ / - 0.15mm'

**OPERATING TEMP:** 

-20°c to 50°c

WALL THICKNESS:

2mm

INSIDE DIAMETER:

25mm

**OUTSIDE DIAMETER:** 

25mm





