CONICAL E/C SAMPLING KIT

(WHABS019C-EC - 25mm)



This Component is used when sampling in a chilled or cold store Environment. The capillary end cap is fed to one end of the pipe run, followed by a 2 meters of capillary 10mm OD nylon tube which links to the conical sampling head which is specially designed to operate in a chilled or cold stores. If ice were to form on the sampling head it forms on the beak, and does not cover the sampling hole allowing the system to continue to function normally.

Installation Instructions:

Use the correct solvent Plusbond 3019. Do not paint. Keep pipe clean and free from dust. Do not install in direct sunlight. Only install with approved pipe. Do not use solvents to clean, only soapy water.

PART NO.: WHABS019C-EC - 25





JOINTING SOCKET WITH CAPILLARY ADAPTOR



10MM NYLON TUBING STANDARD LENGTH 2M



ABS019C/HO CONICAL HEAD M16 Plastic NUT



